

SANDER, BELT 4"

## **OPERATING INSTRUCTIONS**

Install the belt by placing the sander upside down.

Pull belt tension release lever towards rear of tool to release belt.

Pull the old belt free of the pulleys through the open side of the sander.

Leave lever fully released, and place the new belt in position over the pulleys and platen protector.

Belt may have an arrow indicating the direction of rotation, if so follow that direction.

With the belt properly positioned push lever back into its recess to apply proper tension.

Turn tool on by depressing trigger on rear handle.

While depressing trigger push and hold the button on the side of the handle then release trigger.

Belt size is 4"x 24"

## **TROUBLESHOOTING**

Problem:

Belt won't stay on.

Cause:

Belt release not engaged.

Belt is the wrong size.

Problem:

Sander won't stay on.

Cause:

Check and see if power cord is plugged in correctly, and that GFI Breaker or Circuit Breaker in Service Panel has not tripped. Sander may need moved to an outlet served by a different circuit that is not so heavily loaded.

Extension cord may not be working properly.

Extension cord is too short or too long.